



REMOVE ALL TWINE, ROPE AND WIRE FROM ROOT BALL. REMOVE BURLAP FROM TOP HALF OF ROOT BALL CUT AND BALL CUT AND FOLD DOWN BOTTOM HALF

**NOTES:**

1. FOR TREE SPACING, TYPES AND CALIPER, SEE VMC 20.925.060.
2. A ROOT BARRIER SHOULD BE INSTALLED AT THE EDGE OF PAVEMENT OR 4 FEET WIDE AND 6 FEET WIDE RECTANGLE AROUND THE TREE.
3. SCARIFY BOTTOM AND SIDES OF HOLE PRIOR TO PLANTING.

I:\CITYPPS\AUTOCAD\STD\_DETAILS\DRAWING\_FILES\T03-16C

REV NO.	DATE	BY	APPR
1	2/21	OIS	MHA
2	9/21	RAW	MHA

PUBLIC WORKS – STREETS AND TRANSPORTATION

APPROVED BY: *M.H. Pedulla*  
ENGINEER MANAGER

APPROVED DATE: 9/1/2021



DECIDUOUS BALLED/  
BURLAP TREE  
PLANTING

STANDARD PLAN  
NUMBER  
T03-16C