



NOTES:

1. WRAP ALL THREADED FITTINGS W/ 5 WRAPS OF TEFLON TAPE.
2. SWING JOINT SIZE SHALL BE SAME SIZE AS VALVE BOTTOM INLET.

I:\CITYAPPS\AUTOCAD\STD_DETAILS\DRAWING_FILES\T03-09.DWG



QUICK COUPLING VALVE

CITY OF VANCOUVER
DEPARTMENT OF PUBLIC WORKS
TRANSPORTATION DIVISION

DRAWN BY	APPROVED BY	APPROVAL DATE
CDC	<i>M.H.H.</i>	2/07
REVISION	APPROVED BY	APPROVAL DATE
5	<i>M.H.H.</i>	3/24

STD. PLAN NO.
T03-09