



NOTES:

1. WRAP ALL THREADED FITTINGS WITH TEFLON TAPE.
2. MINIMUM SWING JOINT SIZE SHALL BE HEAD BOTH INLET SIZE.
3. WHEN SPRAY HEADS ARE RUNNING ALONG SIDEWALK OR CURBS, HEADS SHOULD BE 3" AWAY AND PIPES 6" OR MORE AWAY.



ROTARY SPRAY HEAD

CITY OF VANCOUVER
DEPARTMENT OF PUBLIC WORKS
TRANSPORTATION DIVISION

DRAWN BY	APPROVED BY	APPROVAL DATE
CDC	<i>MAHE</i>	2/07
REVISION	APPROVED BY	APPROVAL DATE
5	<i>MAHE</i>	3/24

STD. PLAN NO.

T03-14