



**NOTES:**

1. FOR TREE SPACING, TYPES AND CALIPER, SEE VMC 20.925.060.
2. A ROOT BARRIER SHOULD BE INSTALLED AT THE EDGE OF PAVEMENT OR 4 FEET WIDE AND 6 FEET WIDE RECTANGLE AROUND THE TREE.

I:\CITYAPPS\AUTOCAD\STD\_DETAILS\DRAWING\_FILES\T03-16A.DWG



**BARE ROOT PLANTING**

CITY OF VANCOUVER  
DEPARTMENT OF PUBLIC WORKS  
TRANSPORTATION DIVISION

DRAWN BY	APPROVED BY	APPROVAL DATE
CDC	<i>MAHE</i>	2/07
REVISION	APPROVED BY	APPROVAL DATE
6	<i>MAHE</i>	3/24

STD. PLAN NO.  
**T03-16A**