



NOTES:

1. FOR TREE SPACING, TYPES AND CALIPER, SEE VMC 20.925.060.
2. A ROOT BARRIER SHOULD BE INSTALLED AT THE EDGE OF PAVEMENT OR 4 FEET WIDE AND 6 FEET WIDE RECTANGLE AROUND THE TREE.
3. SCARIFY BOTTOM AND SIDES OF HOLE PRIOR TO PLANTING.



DECIDUOUS BALLED / BURLAP TREE PLANTING

CITY OF VANCOUVER
DEPARTMENT OF PUBLIC WORKS
TRANSPORTATION DIVISION

DRAWN BY	APPROVED BY	APPROVAL DATE
CDC	<i>M.H.H.</i>	2/21
REVISION	APPROVED BY	APPROVAL DATE
3	<i>M.H.H.</i>	3/24

STD. PLAN NO.
T03-16C