



## BROADLEAF TREE DETAIL – STAPLED

### NOTES:

- ① AFTER PLANTING AND THOROUGHLY WATERING, APPLY ANTI-DESICCANT SPRAY IF TREE IS IN LEAF.
- ② INSTALL TRUNK GROWTH BASE AT 1" ABOVE FINISH GRADE
- ③ TREE STAPLES, INSTALL 2 PER TREE FOR 2" CAL. & SMALLER TREES & 3 PER TREE FOR LARGER TREES OR IN HIGH WIND LOCATIONS
- ④ 3" DEPTH BARK MULCH OVER COMPOST LAYER IN LAWN AREAS, INSTALL 3' Ø BARK MULCH RING
- ⑤ CONSTRUCT A 3" WATERING BASIN USING SOIL
- ⑥ REMOVE BURLAP FROM TOP 1/2 OF ROOTBALL. REMOVE ANY NON-BIOGRADABLE MATERIAL
- ⑦ BACKFILL: 100% EXTG SOIL FROM HOLE SCARIFY SIDES OF HOLE BEFORE BACKFILLING
- ⑧ TEA BAG TYPE FERTILIZER PACKETS, 20-10-15 W/ MINORS FOLLOW MANUFACTURERS INSTRUCTIONS FOR PLACEMENT; INSTALL 6 PER TREE CALIPER INCH JR SIMPLOT BEST PAKS, OR APPROVE EQUAL
- ⑨ DO NOT OVER-EXCAVATE DIRECTLY UNDER ROOTBALL LOOSEN SOIL NEXT TO ROOTBALL AND SLOPE BOTTOM OF HOLE AWAY FROM ROOTBALL FOR DRAINAGE

### BROADLEAF BALLED / BURLAP TREE PLANTING



CITY OF VANCOUVER  
DEPARTMENT OF PUBLIC WORKS  
TRANSPORTATION DIVISION

DRAWN BY	APPROVED BY	APPROVAL DATE
CDC	<i>M.H.H.</i>	2/21
REVISION	APPROVED BY	APPROVAL DATE
3	<i>M.H.H.</i>	3/24

STD. PLAN NO.

T03-16D