



NOTE:
 THE TEMPERATURE OF HMA SHALL
 BE GREATER THAN 250° F AT TIME
 OF PLACEMENT.

STEPS 2, 3, 4, 5 & 6

MANHOLE ADJUSTMENT

- STEP 1 COVER EXISTING MANHOLE WITH BUILDING PAPER AND CONSTRUCT HMA PAVEMENT OVER TOP OF MANHOLE.
- STEP 2 REMOVE PAVEMENT AROUND MANHOLE 12" MIN. FROM MANHOLE FRAME.
- STEP 3 CLEAN SIDES OF ASPHALT TO ENSURE FREE OF DEBRIS/DUST.
- STEP 4 RAISE MANHOLE FRAME AND COVER USING CONCRETE RINGS AND CITY APPROVED SHIMS, BRICKS, AND CONCRETE TO FINISH GRADE MATCHING PROFILE AND CROSS SLOPE.
- STEP 5 BACKFILL WITH EARLY STRENGTH P.C.C. AND HMA TO DEPTHS AS DIRECTED.
- STEP 6 SEAL AND SAND UPON COMPLETION. SEAL SEAMS WITH BITUMINOUS EMULSION AND ADEQUATELY SAND WHEN COMPLETED.

I:\CITYAPPS\AUTOCAD\STD_DETAILS\DRAWING_FILES\T05-16.DWG



CITY OF VANCOUVER
 DEPARTMENT OF PUBLIC WORKS
 TRANSPORTATION DIVISION

MANHOLE ADJUSTMENT CIRCULAR CUT

DRAWN BY	APPROVED BY	APPROVAL DATE
CDC	<i>M.H.H.</i>	3/24
REVISION	APPROVED BY	APPROVAL DATE
1	<i>M.H.H.</i>	3/24

STD. PLAN NO.
T05-16